



- 1** Check and remove any build-up of adhesive on the ribbed roller
- 2** Rewind spool - loop tape into and out of vertical slot.
1345 Applicator - Re-wind spool turns anti-clockwise.
3653 Applicator - Re-wind spool turns clockwise
This spool has a large, round, black base
- 3** Trigger locks the mechanism. Squeeze trigger to start application, release to stop. Pull away to break adhesive.
- 4** New roll of ATG tape must be positioned so that the small black finger at the base of the turret fits into a cut-out in the core of the roll. Carefully push roll down until retaining catch clicks.

