

Using the Springlock Release Tool and Marker

1

Offer the Marker, 7165, point up, to the SpringLock hole of the bracket. The lock insert should be partially withdrawn.



2

Place the Marker into the hole of the SpringLock bracket.



3

With the Marker Tool in position in the SpringLock, position frame on wall. Gently tap against the frame at the marker position to indicate the exact screw location on the wall.

